



COTTON CANDY MACHINE

Operating Instructions

STEP 1 Turn on the power switch. Let the machine run for 1-2 minutes to allow the motor and drive belt to warm up for best performance. The machine may vibrate while running; this is normal and will not affect operation.

NOTE: Machine has a built in safety switch and will not turn on if the bowl is not fully mounted. All four latches should activate the safety switch. Ensure bowl is in place and secure - red light should be illuminating from the switches.

STEP 2 Turn on the heating switch and allow the head to warm up for 4-5 minutes.

NOTE: To protect candy from debris and prevent the sugar crystals from flying into the air, we suggest purchasing our bubble shield (CANDY-V003) which is sold separately.

STEP 3

OPTION A: CANDY FLOSS SUGAR

If using standard candy floss sugar, pour one scoop full of sugar into the center of the heating head.

OPTION B: HARD CANDY

If using hard candy, turn off the machine and place hard candy pieces evenly in the center of the heating head. Break up into smaller pieces to fit if necessary. Turn machine back on.

WARNING: KEEP HANDS CLEAR OF MOVING PARTS TO REDUCE the RISK OF INJURY

STEP 4 The candy floss will form after roughly 30 seconds. Use a paper cone, candy stick, or other related object to collect the candy floss. Revolve the object in a circular motion following the pan. Turn the object sideways directly over the heating head and continue twisting the object in order to collect the floss into a ball shape.

STEP 5 To continue making candy floss, repeat steps 3 and 4. To prolong the service life of the electric motor, please allow the motor to rest for 20 minutes after working continuously for an hour. Turn off the power switch when you are finished. Remove the pan and clean it with water.

NOTE: If the heating head does not produce candy floss, turn off the power switch and clean the burnt sugar as described in the Cleaning section.

Only use corn syrup based hard candies with a slightly transparent appearance such as Jolly Rancher and Life Savers. Pressed sugar and other hard candies like Smarties may not melt properly, thus clogging the head.